

NIB Utility Chart			LPR Port Name (Case Sensitive)	SmartNetMonitor Administrator (Includes NIB Setup Tool)	SmartNetMonitor Monitor Client	IP-P2P IPX-P2P BootPL Map NW Setup	Multi- Direct Print	NIB Setup Tool	Web Browser Setup (Built in Web Server)	IPP Support	Port Navi	Zone Name (Note 1)
Products	Controller Type/(P-Code)	NIB Type/(P-Code)			O = Supported X = Not Supported							
A229	650/(A852)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A230	450/(A850)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A231	450/(A850)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A232	450/(A850)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A250	185/(B305)	185-E/(B307)	lp	O	O	X	O	O	O	O (Note 2)	O	O
A258	RC-200/(G528)	Built In	lp	O	O	X	O	O	O	O (Note 2)	X	O
A259	RC-200/(G528)	Built In	lp	O	O	X	O	O	O	O (Note 2)	X	O
A260	RC-200/(G528)	Built In	lp	O	O	X	O	O	O	O (Note 2)	X	O
A265	270/(B306)	185-E/(B307)	lp	O	O	X	O	O	O	O (Note 2)	O	O
A267	270/(B306)	185-E/(B307)	lp	O	O	X	O	O	O	O (Note 2)	O	O
A283	450e/(B358)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A284	450e/(B358)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A292	700/(B337)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A293	700/(B337)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A294	850/1085/(B336)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
A295	1050/1105/(B336)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
B001	185/(B305)	185-E/(B307)	lp	O	O	X	O	O	O	O (Note 2)	O	O
B003	1045 (B361)	1045 (G574)	lp	O	O	X	O	O	O	O	O	O
B004	1045 (B361)	1045 (G574)	lp	O	O	X	O	O	O	O	O	O
B006	1045 (B361)	1045 (G574)	lp	O	O	X	O	O	O	O	O	O
B007	1045 (B361)	1045 (G574)	lp	O	O	X	O	O	O	O	O	O
B017	RC-210/(G549)	Built In	lp	O	O	X	O	O	O	X	O	O
B018	RC-210/(G549)	Built In	lp	O	O	X	O	O	O	X	O	O
B022	1027 (B453)	1027 (G335)	lp	O	O	X	O	O	O	O	O	O
B027	1027 (B453)	1027 (G335)	lp	O	O	X	O	O	O	O	O	O
B039	1018 (B405)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
B040	1018 (B405)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
B043	1018 (B405)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
B044	1013 (B441)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
B045	1013 (B441)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
B046	1013 (B441)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
B051	1232(B463)	included	lp	O	O	X	O	O	O	O	O	O
B052	1232(B463)	included	lp	O	O	X	O	O	O	O	O	O
B064	1075(G339)	1075(B525)	lp	O	O	X	O	O	O	O	O	O
B065	1075(G339)	1075(B525)	lp	O	O	X	O	O	O	O	O	O
B070	2105(B580)	B594	lp	O	O	X	O	O	O	O	O	O
B071	2105(B580)	B594	lp	O	O	X	O	O	O	O	O	O
B079	2035(B548)	1075(B525)	lp	O	O	X	O	O	O	O	O	O
B082	2035(B548)	1075(B525)	lp	O	O	X	O	O	O	O	O	O
B089	2027(B577)	1075(B525)	lp	O	O	X	O	O	O	O	O	O
B093	2027(B577)	1075(B525)	lp	O	O	X	O	O	O	O	O	O
B098	1055(B590)	450-E/(A855)	PORT1	O	O	O	X	X	O	X	O	O
G024	Built In	305	lp	O	O	X	O	O	O	O (Note 2)	X	O
G031	Built In	2000/(G919)	PORT1	O	O	O	X	X	O	X	O	O
G032	Built In	2000/(G919)	PORT1	O	O	O	X	X	O	X	O	O
G033	Built In	204	lp	O	O	X	O	O	O	O (Note 2)	X	O
G035	Built In	Built In	PORT1	O	O	O	X	X	O	X	O	O
G038	Built In	Built In	lp	O	O	X	O	O	O	O (Note 2)	O	O
G047	Built In	306	lp	O	O	X	O	O	O	O	O	O
G048	Built In	306	lp	O	O	X	O	O	O	O	O	O
G049	Built In	2000/(G919)	PORT1	O	O	O	X	X	O	X	O	O
G054	Built In	2000/(G919)	PORT1	O	O	O	X	X	O	X	O	O
G056	Built In	2600/(G573)	lp	O	O	X	O	O	O	O	O	O
G058	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G060	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G062	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G063	Built In	306	lp	O	O	X	O	O	O	O	O	O
G065	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G068	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G071	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G073	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G074	Built In	2610/(G646)	lp	O	O	X	O	O	O	O	O	O
G080	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G081	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G082	Built In	Built In	xjprint, xjhold, xjdirect	O	O	X	X	X	O	X	X	X
G091	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G094	Built In	2610/(G646)	lp	O	O	X	O	O	O	O	O	O
G095	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
G570	Built In	Built In	lp	O	O	X	O	O	O	O	O	O
H306	500/(H144)	2000/(G919)	PORT1	O	O	O	X	X	O	X	X	O
H310	(510)B516	Built In	lp	O	O	X	O	O	O	O	O	O
H311	(510)B516	Built In	lp	O	O	X	O	O	O	O	O	O
H555	1013 (B441)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
H556	1013 (B441)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O
H557	1013 (B441)	1018 (B430)	PORT1	O	O	O	X	X	O	X	O	O

Note 1: The Zone Name is available to be changed using the Zonename.PS file or Web Status Monitor (depend on the firmware version of the controller)  
 Note 2: NIB Firmware must be version 3.9.2 or higher